

OHD Quantifit Adapter

OHD Kit #40 Moldex 7000 & 9000 Series

The OHD Kit #40 is for use with Moldex 7000 series (half-face) and 9000 series (full-face.)

IMPORTANT: In order for this adapter to work properly, the inhalation valve must be removed (by carefully detaching them from the pins on the inside of the mask) or propped open (by using a folded coffee stir, straw, tubing, or some other convenient object.) If the inhalation valves are not removed or opened, the test results will not be valid.



Moldex 7000 Series Respirator



Use a simple object like a coffee stir to prop open the inhalation valves.



Moldex 9000 Series Respirator



OHD Kit #40